


# Windows OS



# Windows OS

- Windows is an operating system that was first launched in 1985 by Microsoft
- Windows is known with a convenient graphical user interface, using Windows and Mouse
- Today, the operating system is the most common in the world and runs on all PCs and servers

# Windows OS



# Windows 1.0

MS-DOS Executive

A ━━━━ A:WIN101 \


ABC.TXT	CLOCK.EXE	HELVIA.FON	MSDOS.EXE	REVERSI.EXE	TMSRB.FON
AUTOEXEC.BAT	COMMAND.COM	HELVB.FON	MSDOSD.EXE	ROMAN.FON	WIN.CNF
CALC.EXE	CONTROL.EXE	HIFONTS.FON	NOTE PAD.EXE	SCRIPT.FON	WIN.COM
CALENDAR.EXE	COURA.FON	HPLASER.DRU	PAINT.EXE	SPOOLER.EXE	WIN.INI
CARDFILE.EXE	COURB.FON	LOFONTS.FON	PRACTICE.DOC	TERMINAL.EXE	WIN100.BI
CLIPBRD.EXE	DOTHIS.TXT	MODERN.FON	README.DOC	TMSRA.FON	WIN100.OU

Paint - (untitled)

File Edit Font FontSize Style Palette Options

HDIRIM  
00:DE:F5:EC:01:11

# Windows Evolution



Windows 1  
1985



Windows 3.1  
1992



Windows 95  
1995



Windows XP  
2001



Windows Vista  
2006



Windows 7  
2009




Windows 8  
2012



Windows 10  
2015

# Windows Desktop OS Evolution



# Windows - Commands

- hostname - Shows the name of the computer I am logged in

```
Microsoft Windows [Version 10.0.17134.950]
(c) 2018 Microsoft Corporation. All rights reserved.

C:\Users\itaym>hostname
makisPC2
```

- whoami - Shows the name of the user I am logged in

```
C:\Users\itaym>whoami
makispc2\itaym
```

- Useful in case of switching between users

# Windows - Commands

- whoami \groups – shows a list of user's groups permission

```
C:\Users\itaym>whoami /groups

GROUP INFORMATION
-----
Group Name                               Type          SID
                                         Attributes
=====
Mandatory Label\Medium Mandatory Level   Label         S-1-16-8192
Everyone                                Well-known group S-1-1-0
                                         Mandatory group, Enabled by default
, Enabled group
NT AUTHORITY\Local account and member of Administrators group Well-known group S-1-5-114
                                         Group used for deny only
BUILTIN\Administrators                   Alias         S-1-5-32-544
                                         Group used for deny only
BUILTIN\Users                            Alias         S-1-5-32-545
                                         Mandatory group, Enabled by default
, Enabled group
```

# Windows - Commands

- Ipconfig /all - Displays computer's network cards IP addresses and MAC addresses

```
Wireless LAN adapter Wi-Fi:

Connection-specific DNS Suffix . :
Description . . . . . : Intel(R) Wireless-AC 9560
Physical Address. . . . . : 38-BA-F8-E8-10-5C
DHCP Enabled. . . . . : Yes
Autoconfiguration Enabled . . . . . : Yes
IPv4 Address. . . . . : 10.60.46.3(Preferred)
Subnet Mask . . . . . : 255.255.255.0
Lease Obtained. . . . . : 20 August, 2019 04:02:51 PM
Lease Expires . . . . . : 20 August, 2019 04:40:49 PM
Default Gateway . . . . . : 10.60.46.254
DHCP Server . . . . . : 10.193.2.1
DNS Servers . . . . . : 185.149.252.250
                           208.67.222.222
NetBIOS over Tcpip. . . . . : Enabled
```

# Windows - Commands

- Ping – network connectivity check

```
C:\Users\itaym>ping 10.60.46.254

Pinging 10.60.46.254 with 32 bytes of data:
Reply from 10.60.46.254: bytes=32 time=3ms TTL=254
Reply from 10.60.46.254: bytes=32 time=2ms TTL=254
Reply from 10.60.46.254: bytes=32 time=2ms TTL=254
Reply from 10.60.46.254: bytes=32 time=3ms TTL=254
```

# Windows - Commands

- tracert – network connectivity to each router hop to chosen IP address

```
C:\Users\itaym>tracert -d 8.8.8.8

Tracing route to 8.8.8.8 over a maximum of 30 hops

  1      5 ms       3 ms       2 ms    192.168.43.1
  2     58 ms      256 ms     235 ms   10.194.248.150
  3     49 ms       27 ms      26 ms   192.168.249.113
  4     81 ms       29 ms      35 ms   192.168.234.1
  5       *          *          *       Request timed out.
  6     49 ms       22 ms      29 ms   192.168.234.17
  7       *          *          *       Request timed out.
  8    298 ms      191 ms      32 ms   82.102.132.78
  9     88 ms       88 ms      87 ms   80.179.166.142
 10    112 ms      98 ms      95 ms   72.14.216.121
 11    111 ms     103 ms      97 ms   108.170.251.129
 12     89 ms       89 ms      87 ms   66.249.94.245
 13    102 ms     100 ms      85 ms   8.8.8.8
```

# Windows - Commands

- arp - a

```
c:\Users>arp -a

Interface: 192.168.43.166 --- 0x7
  Internet Address          Physical Address      Type
  192.168.43.1              4a-2c-a0-3c-16-01  dynamic
  192.168.43.255            ff-ff-ff-ff-ff-ff  static
  224.0.0.22                 01-00-5e-00-00-16  static
  224.0.0.251                01-00-5e-00-00-fb  static
  224.0.0.252                01-00-5e-00-00-fc  static
  239.255.255.250            01-00-5e-7f-ff-fa  static
  255.255.255.255            ff-ff-ff-ff-ff-ff  static
```

# Windows - Commands

- nslookup - The DNS Query request serves to DNS server to identify an IP address / URL

```
c:\Users>nslookup 8.8.8.8  
Server: UnKnown  
Address: 192.168.43.1  
  
Name: dns.google  
Address: 8.8.8.8
```

```
c:\Users>nslookup dns.google  
Server: UnKnown  
Address: 192.168.43.1
```

```
Non-authoritative answer:  
Name: dns.google  
Addresses: 2001:4860:4860::8844  
          2001:4860:4860::8888  
          8.8.8.8  
          8.8.4.4
```

# Windows - Commands

- route print – display all the routings that configure

Active Routes:						
Network Destination	Netmask	Gateway	Interface	Metric		
0.0.0.0	0.0.0.0	192.168.43.1	192.168.43.166	55		
127.0.0.0	255.0.0.0	On-link	127.0.0.1	331		
127.0.0.1	255.255.255.255	On-link	127.0.0.1	331		
127.255.255.255	255.255.255.255	On-link	127.0.0.1	331		
169.254.0.0	255.255.0.0	On-link	169.254.68.2	281		
169.254.0.0	255.255.0.0	On-link	169.254.152.173	281		
169.254.68.2	255.255.255.255	On-link	169.254.68.2	281		
169.254.152.173	255.255.255.255	On-link	169.254.152.173	281		
169.254.255.255	255.255.255.255	On-link	169.254.68.2	281		
169.254.255.255	255.255.255.255	On-link	169.254.152.173	281		
192.168.43.0	255.255.255.0	On-link	192.168.43.166	311		
192.168.43.166	255.255.255.255	On-link	192.168.43.166	311		
192.168.43.255	255.255.255.255	On-link	192.168.43.166	311		
224.0.0.0	240.0.0.0	On-link	127.0.0.1	331		
224.0.0.0	240.0.0.0	On-link	169.254.68.2	281		
224.0.0.0	240.0.0.0	On-link	169.254.152.173	281		
224.0.0.0	240.0.0.0	On-link	192.168.43.166	311		
255.255.255.255	255.255.255.255	On-link	127.0.0.1	331		
255.255.255.255	255.255.255.255	On-link	169.254.68.2	281		
255.255.255.255	255.255.255.255	On-link	169.254.152.173	281		
255.255.255.255	255.255.255.255	On-link	192.168.43.166	311		
=====						
Persistent Routes:						
None						

# Windows - Commands

- route - Create, view and delete existing routings
  - route add – route add –p { network and mask } via { gateway IP }
  - route delete – route add –p { network and mask } via { gateway IP }

# Windows - Commands

- telnet - Perform an attempt to connect to communication equipment or servers
- Mainly used to check the network connection in front of a destination IP

```
c:\Users>telnet 8.8.8.8 23  
Connecting To 8.8.8.8...
```

```
c:\Users>telnet 8.8.8.8 443
```

# Windows - Commands

- netstat –noa
- View network traffic on the local computer

TCP	192.168.43.166:139	0.0.0.0:0	LISTENING	4
TCP	192.168.43.166:49410	52.139.250.253:443	ESTABLISHED	4772
TCP	192.168.43.166:50872	52.139.250.253:443	ESTABLISHED	12876
TCP	192.168.43.166:50878	108.177.126.188:5228	ESTABLISHED	13420
TCP	192.168.43.166:51214	23.221.151.154:443	CLOSE_WAIT	12084
TCP	192.168.43.166:51215	23.221.151.154:443	CLOSE_WAIT	12084
TCP	192.168.43.166:51216	23.221.151.154:443	CLOSE_WAIT	12084
TCP	192.168.43.166:51219	23.221.151.154:443	CLOSE_WAIT	12084
TCP	192.168.43.166:51220	23.221.151.154:443	CLOSE_WAIT	12084
TCP	192.168.43.166:51223	23.221.142.3:80	CLOSE_WAIT	12084
TCP	192.168.43.166:51224	23.221.142.3:80	CLOSE_WAIT	12084
TCP	192.168.43.166:51225	23.221.142.3:80	CLOSE_WAIT	12084

# Windows - Commands

- cd: Switch between folders
- dir: display list of all the files

```
C:\Users\itaym>
C:\Users\itaym>
C:\Users\itaym>cd c:\

c:\>cd users

c:\Users>dir
 Volume in drive C has no label.
 Volume Serial Number is 44CD-ADA5

 Directory of c:\Users

19-Aug-19  05:26 PM    <DIR>          .
19-Aug-19  05:26 PM    <DIR>          ..
19-Aug-19  05:27 PM    <DIR>        Itay-TEST
20-Aug-19  03:49 PM    <DIR>        itaym
02-Nov-18  07:58 AM    <DIR>        Public
                           0 File(s)           0 bytes
                           5 Dir(s)  157,979,435,008 bytes free
```

# Windows - Commands

- echo <string> > <file\_name>
- type NUL > <file\_name> : create empty file
- del <file\_name>: delete the file

```
C:\Users\itaym>echo TEST > TEST.txt
C:\Users\itaym>dir
Directory of C:\Users\itaym
20-Aug-19  06:19 PM                7 TEST.txt
```

```
C:\Users\itaym>type NUL > TEST2.txt
C:\Users\itaym>del TEST2.txt
```

# Windows - Commands

- task list: Display all the running processes on your computer

```
C:\Users\itaym>tasklist

  Image Name                   PID Session Name     Session#    Mem Usage
  ====== ====== ====== ====== ======
System Idle Process           0  Services          0          8 K
System                         4  Services          0        7,684 K
Registry                       120 Services         0       28,296 K
smss.exe                      512 Services         0        976 K
csrss.exe                     532 Services         0       4,712 K
wininit.exe                   1068 Services        0       5,400 K
csrss.exe                     1084 Console          1       5,916 K
services.exe                  1144 Services         0      10,728 K
lsass.exe                      1160 Services        0      17,296 K
winlogon.exe                  1244 Console          1       9,576 K
svchost.exe                   1356 Services         0       5,616 K
Fontdrvhost.exe               1376 Services         0        2,600 K
Fontdrvhost.exe               1384 Console          1       9,736 K
WUDFHost.exe                 1428 Services         0        7,336 K
svchost.exe                   1484 Services         0      30,904 K
WUDFHost.exe                 1544 Services         0      15,036 K
```

# Windows - Commands

- task kill: ending specific running processes on your computer

```
C:\Users\itaym>taskkill /PID 18724
SUCCESS: Sent termination signal to the process with PID 18724.
```

- sc: display all the services running on your computer

```
C:\Users\itaym>sc query

SERVICE_NAME: AdobeARMService
DISPLAY_NAME: Adobe Acrobat Update Service
    TYPE               : 10  WIN32_OWN_PROCESS
    STATE              : 4   RUNNING
                           (STOPPABLE, NOT_PAUSABLE, IGNORES_SHUTDOWN)
    WIN32_EXIT_CODE    : 0   (0x0)
    SERVICE_EXIT_CODE : 0   (0x0)
    CHECKPOINT        : 0x0
    WAIT_HINT         : 0x0
```

Q\A

